

Camlock Reducer 2" to 1.5" Installation Instructions



Remove the dust cap from the tote valve.



Remove the tamper evident NSF seal from the tote valve.



Attach the 1.5" hose to the camlock adapter.



Attach camlock adapter to tote valve with ears towards the tote.



Pull ears towards you until camlock is locked in place.



Once locked in properly, the camlock will be secure.



Attach other end of hose to 1.5" pumping system and finish setting up circulation system.



Camlock reducer 2" to 1.5".

Available now for \$29.00 - Part Number: PV2-CAMRED015